The top sand stone was A little soft and there was A soft spot

390' with some caving so I put the 4" liner in. To stop any sand

from getting in the well and to stop any chance of anything

from caving in 11 is Grouten with neat cement from the

Bottom up.



